



AUSTRALIAN
**SURFACING
SUPPLIES** PTY LTD

Playkote

INSTALLATION DETAILS

ITEMS YOU WILL NEED

**Straight edged trowel, Small paint brush, Bucket with soapy water
Rubber Heavy Duty waterproof gloves, Stanley Knife**

1. Cut a straight edge, using the straight edge trowel around the perimeter of the damaged rubber surface.
2. Clean out the area, remove all loose rubber, soil and vegetation.
3. With the small paint brush place a small amount of binder on to the brush and coat around the edge of the inside of the damaged area only.
4. Pour the rest of the binder onto the granules in the large tub. Mix the rubber and binder together until all granules are coated with binder. Use either a mixing stick or large rubber waterproof gloves. (Put the Latex gloves on first and wear these at all times).
5. Pour a small amount of rubber into the damaged area. Dip the trowel into the soapy water, this will prevent the rubber from sticking to the trowel. Press and screed until level, repeat until the area is filled and at the same thickness of the existing surface.
6. Once completed place the empty binder bottle, brush, latex gloves, and any other rubbish into the large tub and dispose of as per your local refuse regulations.
7. Leave area to cure for at least 24 hours.

PHONE **1300 752 956**

sales@australiansurfacingssupplies.com.au

www.australiansurfacingssupplies.com.au

Offices: Adelaide, Melbourne, Sydney, Brisbane



AUSTRALIAN
**SURFACING
SUPPLIES** PTY LTD

Playkote 

Items you will require to carry out the repair:

Gloves – We recommend you use both a Latex glove and a Rubber Glove.

Sharp Knife – Heavy duty Retractable Knife for cutting the rubber surface.

Straight edge trowel – Used for cutting a straight edge with the knife and for screeding the rubber granules.

Washing Liquid – Small amount of washing liquid in water enough to put your trowel into.

Bucket – For water / Washing Liquid

Stirring Handle – Use a mixing stick or anything that will easily mix the rubber and binder together. You could easily do this by wearing the Rubber Gloves and mixing by hand. Do not mix the granules/binder with just the Latex gloves or no gloves at all.

Paint Brush – Use the brush to apply binder around the inside of the existing rubber surface, this will help bond the new surface to the old surface.

Tape Measure – Check the thickness and area size.

Cleaning your tools after use – With White Spirit or warm soapy water and a clean cloth or brush.



PHONE **1300 752 956**

sales@australiansurfacing.com.au

www.australiansurfacing.com.au

Offices: Adelaide, Melbourne, Sydney, Brisbane