



AUSTRALIAN
**SURFACING
SUPPLIES** PTY LTD

PlayKote

PLAYKOTE WET POUR RUBBER DIY REPAIR KITS



Australian Surfacing Supplies' Wet Pour Rubber repair kits are easy to install, with a wide range of colours available.

Each kit contains:

- 20 litre Bucket
- 12.5kg of Rubber Granules
- 2kg of Binder
- 1 x set of Latex Gloves
- Installation Instructions



Each kit will cover approx:

1 sqm @ 15mm thickness
1.5 sqm @ 10mm thickness



Need a quick fix for worn or damaged rubber surfaces? Let's chat!



AUSTRALIAN
**SURFACING
SUPPLIES** PTY LTD

PlayKote

PLAYKOTE WET POUR RUBBER DIY REPAIR KITS

Damaged rubber surfacing?

Don't replace the whole area -
repair it in no time with our
Wet Pour Repair Kits!



Fast & Simple Application

As easy as **1, 2, 3...**



1

Prepare the damaged surface

- Clear the debris
- Cut a border around the damaged area at a 45 degree angle



2

Mix the Binder and Rubber

- Mix the binder and rubber in the bucket supplied
- The correct ratio of rubber and binder is provided in every kit



3

Pour the mixture into the damaged area

- Level off the area with a trowel
- Use soapy water to lubricate the trowel to avoid the rubber sticking
- Leave the area to cure for at least 24 hours

*For detailed instructions refer to the QR Code on every repair kit

17/04/2026